



Drill holes in back support brace at wall stud locations. Fasten vanity to wall using fasteners of your choice through the support brace into wall studs.