

**DO NOT RETURN TO RETAILER
IF YOU HAVE ANY
QUESTIONS OR CONCERNS
PLEASE CALL
BOND MANUFACTURING
TOLL FREE AT
+1-866-771-BOND(2663)
MONDAY - FRIDAY 8AM TO 4:30 PM PST
OR EMAIL TO
Customer.service@bondmfg.com
OR VISIT OUR WEBSITE AT
www.bondmfg.com**

Assembly Instructions

Item#: Y95826

*** * WARNING * ***

Read these instructions carefully and keep the fountain power off until the following assembly process is strictly completed.

Notes:

- Choose an appropriate location for the fountain.
- Excessive weight or pressure on any of the fountain sections may cause it to fall. Keep pets, children, or anyone from sitting, leaning, or climbing on any of the fountain components.
- While fountain is designed to operate as splash free as possible, some water splashing out of the fountain is inevitable. Place the fountain in a location where any splashing will not cause damage.
- The National Electric Code requires that a ground fault circuit interrupter (GFCI) be used in the branch circuit supplying fountain pump and other pond equipment. Seek your electrical supplies dealer for this device.
- Always keep the fountain working with sufficient water and clean of debris and dirt to ensure proper functioning of the pump.
- If necessary, clean the fountain with a soft cloth and change the water frequently. Due to water evaporation, you may see a buildup of white residue on the fountain surface from mineral content in the water supply. To prevent such buildup, regularly clean the fountain with soap and water. Do not use any abrasive, which may damage the applied finish.
- **Use of water clarifier or algaecide of any kind will damage the paint on the fountain and will not be covered under the manufactures warranty.**
- See the pump instructions for pump safety, maintenance, and warranty information.
- Keep this manual for future reference.

Installation & Assembly

- Place the fountain on a level surface, away from areas where it is likely to get clogged with leaves and make sure that the cable will reach the socket.
- Take out all the packaged parts from the carton.
- Follow steps to assemble as illustrated below.

Step (1) Match the upper set with the base one and meanwhile put the PVC tube & cable line in the whole of the base set. See picture ① & ② & ③.

Step (2) Make sure the upper set can match with the base well, see picture ④ & ⑤.



Step (3) Pull out the PVC tube from the back door of the fountain, then connect it with the pump, which is shown in ⑥.

Step (4) Pull out the cable line of the light from the back door of the fountain, then connect the connector of LED light to the adaptor, shown in ⑦.

Step (5) Closed up the back cover to the fountain as shown in ⑧.




Step (6) Fill the reservoir with clean water carefully. Always make sure the water is high enough to submerge the pump completely. This ensures the pump can work properly and prevents damage to the pump. Plug the pump and adaptor then switch on, the water will start to flow in minutes, and lights will be shining instantly.


- Adjust the pump flow rate to achieve the desired effect and to minimize any splashing, shown as **(F)**. Splashing can occur if the flow rate is too high or the reservoir is too full. The flow rate can be increased or decreased by moving the flow rate control slider on the pump body. Moving the slider towards '+/Max.' will increase the flow rate and moving it towards '-/Min' will decrease it. On some type of pumps, the flow regulator may be turned clockwise or counterclockwise to adjust.



- ⌚ Clockwise Full Flow
- ⌚ Counterclockwise Reduced Flow

Assemble Diagram





Troubleshooting

-- TURN OFF THE POWER BEFORE YOU CHECK FOLLOWING--

If pump does not run, or lights are not on --

- (1) Check the circuit breaker, try another outlet.
- (2) Check the water level in the fountain. Running the pump without sufficient water can damage the pump.
- (3) Check the setting of the flow control on the pump and adjust the flow.
- (4) Check the pump discharge and intake for dirt and debris.
- (5) Check the fountain feature tubing for kinks and obstructions.
- (6) The pump might be "air locked". Plug and unplug the pump several times to release the air inside the pump.
- (7) Check and reconnect all the cords and try again.

IF YOU HAVE QUESTIONS OR CONCERNS PLEASE

CALL BOND'S TOLL FREE #

1-866-771-BOND(2663) OR TO BETTER

EXPEDITE YOUR REQUEST FEEL FREE TO EMAIL US

customer.service@bondmfg.com

OR LOG IN TO OUR WEBSITE UNDER CUSTOMER SERVICE SUPPORT

www.bondmfg.com

Jebao




SUBMERSIBLE PUMP

OWNER'S MANUAL

INTRODUCTION

Jebao pumps are carefully inspected and tested to insure both safety and operating performance. However, failure to follow the instructions and warnings in this manual may result in pump damage and or serious injury. Be sure to read and save this manual for future reference.



■ WARNING!

- This pump is supplied with a grounding conductor and a grounding type attachment plug. To reduce the risk of electric shock, connect only to a properly grounded outlet.
- Do not remove the grounding pin from the plug.
- Do not connect to any voltage other than what the pump is rated for.
- Do not pump flammable liquids.
- The national electric code requires that a Ground Fault Circuit Interrupter (GFCI) be used in the branch circuit supplying fountain pumps and other pond equipment. See your electrical supply dealer for this device.
- To reduce the risk of electrical shock, use only on portable self-contained fountains no larger than 5 feet in any dimension.
- Do not use with water above 86°F (30°C)

■ CAUTION

Always disconnect from electrical outlet before handling the pump.

Do not let the pump run dry.

Do not lift the pump by the power cord.

Do not pump heated liquids.

Operate in freshwater only.

Operate the pump only when completely submerged for proper cooling.

■ PERFORMANCE

- A clogged or dirty intake screen will greatly reduce performance. If the pump is used on a dirty surface, raise it slightly to reduce the amount of debris contacting the intake. If less flow is desired, adjust the flow control lever on the side of the pump or restrict the discharge flow.
- Do not let the pump run when not submerged in water. Doing so may damage the pump. Always submerge the pump first, and then plug into an electrical outlet. When you first use the pump there may be air in the pump causing water not to flow. Prime the pump by plugging and unplugging the pump from the power source until water starts to flow.




■ MAINTENANCE

To clean the pump, remove the front cover and the impeller. Use a small brush or stream of water to remove any debris.

IF THE PUMP FAILS TO OPERATE, CHECK THE FOLLOWING:

- Check the circuit breaker and try another outlet to ensure the pump is getting electrical power. NOTE: Always disconnect from electrical outlet before handling the pump.
- Check the pump discharge and tubing for kinks and obstructions. Algae build up can be flushed out with a garden hose.
- Check the inlet screen to insure it is not clogged with debris.
- Remove the pump inlet to access the impeller area. Turn the rotor to ensure it is not broken or jammed.
- Monthly maintenance will add to your pump's life.

NOTE: Insure that the electrical cord loops below the electrical outlet to form a "Drip Loop" This will prevent water from running down the cord into the electrical outlet.



LIMITED WARRANTY

This product is guaranteed for a period of 12 months from date of purchase for material or manufacturing defects certificate of guarantee must be filled out completely by resale dealer and must accompany equipment along with the receipt in case it is submitted for repair Guarantee consists in guaranteed substitution of defective parts Guarantee is considered void in case of improper use, nor does it answer to damage caused by improper handling or negligence on the part of the buyer. All equipment must be sent postage paid.
